







## Pump Vault 15000/55000 Increase 55000

DE	Gebrauchsanleitung
EN	Operating instructions
FR	Notice d'emploi
NL	Gebruiksaanwijzing
ES	Instrucciones de uso
PT	Instruções de uso
IT	Istruzioni d'uso
DA	Brugsanvisning
NO	Bruksanvisning
SV	Bruksanvisning
FI	Käyttöohje
HU	Használati útmutató
PL	Instrukcja użytkowania
CS	Návod k použití
SK	Návod na použitie
SL	Navodila za uporabo
HR	Uputa o upotrebi
RO	Instrucțiuni de folosință
BG	Упътване за употреба
UK	Посібник з експлуатації
RU	Руководство по эксплуатации
CN	使用说明书











	<p><b>Pump Vault 15000</b> Aquarius Universal Premium 12000</p>	<p><b>Pump Vault 55000</b> Aquarius Universal Premium 20000 Aquarius Eco Expert 28000</p>	<p><b>Increase 55000</b> —</p>
---	---	---	------------------------------------






Pump Vault 15000



Pump Vault 55000



Increase 55000




PVT0003



### Pump Vault 15000


Ø max. 38 mm




Water Replenishment System

### Pump Vault 55000



4x 



### Increase 55000



PVT0004



PVT0007

