

Oase




Eco-Rise

30, 50


DE	Gebrauchsanleitung	HU	Használati útmutató
EN	Operating instructions	PL	Instrukcja użytkowania
FR	Notice d'emploi	CS	Návod k použití
NL	Gebruiksaanwijzing	SK	Návod na použitie
ES	Instrucciones de uso	SL	Navodila za uporabo
PT	Instruções de uso	HR	Uputa o upotrebi
IT	Istruzioni d'uso	RO	Instrucțiuni de folosință
DA	Brugsanvisning	BG	Упътване за употреба
NO	Bruksanvisning	UK	Посібник з експлуатації
SV	Bruksanvisning	RU	Руководство по эксплуатации
FI	Käyttöohje	CN	使用说明书




Eco-Rise 30
(87091)



Eco-Rise 50
(72937)




ERE0004



Eco-Rise 30

Maxima



Eco-Rise 30, 50


Eco-Rise 50

Water Reservoir


ERE0001



Eco-Rise 30




Eco-Rise 50




ERE0003



Eco-Rise 30



Eco-Rise 50



ERE0002

OASE GmbH
Tecklenburger Straße 161
48477 Hörstel | Germany
☎ +49 (0) 5454 80-0
📠 +49 (0) 5454 80-9353
✉ info@oase.com

72975/01-22